


COPELAND FURNITURE	Catalina Bed assembly instructions
Side Rail Assembly x2	Headboard Assembly x1 Platform Assembly x6
Notice: Beds must be disassembled b	Footboard Assembly x1 before moving to avoid damage. Never attempt to move the bed while it is assembled.
Failure to do so would void the warranty. Your Catalina bed is delivered in four boxes. Unpack the bed parts onto a soft, level surface in the space where the bed is to be used. Lay out the headboard, side rails and footboard in their approximate locations.	
Tools required for assembly - Straight and right angle wrenches (included) and Phillips Head Screw Driver.	
Hardware List	
Threaded Rods (8)	#10 x 1 1/2" Screws (12)
Nuts (8)	#8 x 1 3/4" Screws (3)
Washers (8)	
Straight Wrench	
Right Angle Wrench	Packaged By
www.copelandfurniture.com	

Catalina Bed - assembly instructions






Slide a **side rail** onto the headboard using the dowel in the end of the rail and the threaded rod as a guide. Place a **washer and hex nut** over each rod. Fully tighten with the provided **straight wrench**.



www.copelandfurniture.com



Important: Please Note:

Beds must be disassembled before moving to avoid damage. Never attempt to move the bed while it is assembled.

To care for and preserve the finish on your new Copeland Furniture piece, please keep the following recommendations in mind.

- While our furniture has been finished with a durable top coat, the surface may be sensitive to dents and abrasions during the first 30 days in your home.
- Treat the surface finish gently so it does not dent or chip. Tape or stickers should not be put on the finish.
- For general care use a soft cloth to dust the furniture.
- Use damp cloth with a mild soap to clean-up spills or dirt. Dry the surface thoroughly.
- Please do not use any polishes, waxes or solvents to clean the surface of the furniture. This holds true for new Copeland Furniture pieces as well as items you may already have in your home.
- Please do not place any candles directly on the surface of your furniture. The perfumes and dyes in the candles may penetrate the finish.

Special Care Instructions for Cherry Furniture - *Please read the following if you have purchased a Copeland product in cherry.*

Furniture that has been crafted from cherry wood becomes darker with age. The change in color, from a reddish tan to a reddish brown, is most noticeable during the first six months of ownership. It is important to understand that exposure to light accelerates the natural oxidization process. An object left on a cherry wood surface for an extended period of time may retard the aging process in a limited area. Simply remove the object and, over time, the surface will attain a uniform reddish brown color.



If you have any questions or difficulties, please call us at the number below between the hours of 8:00 am and 4:30 pm eastern time. **156 Industrial Drive, Bradford, VT 05033 Tel: 802.222.9282 Fax: 802.222.9285 www.copelandfurniture.com**