

ASSEMBLY INSTRUCTIONS FOR #139590


IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED

THIS FIXTURE WEIGHS OVER 50 LBS. NEC:314.27B, A luminaire that weighs more than 23kg (50lb) shall be supported independently of the outlet box unless the outlet box is listed AND MARKED for the MAXIMUM weight to be supported.

- 1.) Mount canopy to a secure location.
- 2.) Attach support loop to crossbar using crossbar nipple.
- 3.) Attach fixture chain to frame loop using quick link.
- 4.) Slide both the canopy nut and canopy down fixture chain as shown.
- 5.) Thread electrical wires up fixture chain, through canopy nut, canopy, and crossbar nipple.
- 6.) Wire as per local electrical codes.
- 7.) Slide canopy up fixture chain to ceiling and secure with canopy nut.



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00 a.m. - 6:00 p.m. ET

visit us on the web at www.meyda.com