



ASSEMBLY INSTRUCTIONS FOR # 141071, 141072, 141073




IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED

- 1.) Remove face plate from fixture frame by unscrewing the tamper proof screws with the screw driver provided.
- 2.) Remove fixture frame from back plate by unscrewing mounting nuts from mounting studs.
- 3.) Determine mounting point on wall.
- 4.) Drill any necessary mounting holes and power hole into the back plate.
- 5.) Use the wire gauge sheet to determine which wire is needed. (keeping in mind that the power supply must be mounted in a dry location)
- 6.) Wire as per local electrical codes.
- 7.) Mount back plate to a secure location using customer provided screws.
- 8.) Attach fixture frame to back plate and secure with mounting nuts.
- 9.) Attach face plate to fixture frame and secure with tamper proof screws.



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00a.m - 6:00p.m ET

visit us on the web at www.meyda.com