



Dimensions

B - Seat Height - 19.5"/ 50cm C - Arm Height - 26.5"/ 67cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Outside handle mechanism
- Toggle power mechanism

41098 DURANT



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. **LHF** - left hand facing **RHF** - right hand facing **IA** - inside arm to inside arm.





03-Stationary Loveseat 04-Home Theater









66 x 39 x 40" 168 x 99 x 102cm

Ottoman 44 x 28 x 19" 112 x 71 x 48cm



Chair

09-Corner Curve 47 x 39 x 40" 119 x 99 x 102cm

46-RHF Recliner Chair

47-LHF Recliner Chair

67-LHF Recliner Pwr

33 x 39 x 40"

83 x 99 x 102cm




51-Sofa Recliner 61-Sofa Recliner Pwr 88 x 39 x 40"

10-Armless Chair

58 x 99 x 102cm

23 x 39 x 40"

223 x 99 x 102cm IA: 64" / 163cm





Recliner, Drop Table

Table

62-Power Sofa

223 x 99 x 102cm

IA: 64" / 163cm

88 x 39 x 40"



53-Loveseat Recliner 63-Loveseat Recliner

27-RHF Sofabed 54"

183 x 99 x 102cm

Pwr 66 x 39 x 40" 167 x 99 x 102cm IA: 42" / 107cm

30-Armless Recliner 60-Armless Recliner Pwr

23 x 39 x 40" 58 x 99 x 102cm 31-Wallhugger Recliner 66-RHF Recliner Pwr Chair Pwr 33-Swivel Rocker Recliner Chair 35-Wallhugger Recliner Chair

32-Rocker Recliner

39-Power Rocker Recliner 42 x 39 x 40" 106 x 99 x 102cm IA: 18" / 46cm



‡ | **‡**©

58-Loveseat Console 68-Loveseat Console

Pwr 79 x 39 x 40" 200 x 99 x 102cm

A0-11 Degree Storage Wedge 17 x 36 x 36"

43 x 91 x 91cm 91 x 91 x 91cm

A1-45 Degree Storage Wedge 36 x 36 x 36"

A2-Storage Console 13 x 36 x 36" 33 x 91 x 91cm



How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

41098 DURANT

PALLISER®

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.




CONFIGURATION MA

106 x 106" 269 x 268cm




CONFIGURATION MF

123 x 71" 311 x 180cm




CONFIGURATION MB

103 x 122" 261 x 310cm



CONFIGURATION MG

162 x 75" 410 x 191cm




CONFIGURATION MD

116 x 122" 294 x 310cm



CONFIGURATION MH

115 x 67" 291 x 170cm



CONFIGURATION ME

164 x 76"

417 x 192cm



CONFIGURATION MI

151 x 67"

382 x 170cm