




77287 INDIA

PALLISER®

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing **RHF** - right hand facing **IA** - inside arm to inside arm.



01-Sofa

83 x 39 x 36"
 211 x 99 x 91cm
 IA: 69" / 175cm



02-Chair

37 x 39 x 36"
 94 x 99 x 91cm
 IA: 23" / 58cm




03-Loveseat

60 x 39 x 36"
 152 x 99 x 91cm
 IA: 46" / 117cm




04-Ottoman

22 x 22 x 16"
 56 x 56 x 41cm



62-Pushback Chair

37 x 35 x 40"
 94 x 89 x 102cm
 IA: 22" / 56cm



Dimensions

A - Seat Depth - 21" / 53cm

B - Seat Height - 20" / 51cm

C - Arm Height - 26" / 66cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre



77287 INDIA

PALLISER®

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled

Components - five year pro-rated warranty

