




77494 JUNO

PALLISER®
My Home, My Style, My Way™

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside



Dimensions


A - Seat Depth - 21" / 53cm

B - Seat Height - 18" / 46cm

C - Arm Height - 26" / 66cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: Premium elastic webbing offers consistent suspension for the life of the product
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort




01 Sofa
87 x 37 x 33"
221 x 94 x 84cm
IA: 66" / 168cm



02 Chair
23 x 37 x 33"
58 x 94 x 84cm



03 Loveseat
65 x 37 x 33"
165 x 94 x 84cm
IA: 44" / 112cm



04 Ottoman
23 x 23 x 17"
58 x 58 x 43cm




08 RHF Loveseat
07 LHF Loveseat
55 x 37 x 33"
140 x 94 x 84cm



15 RHF Chaise
16 LHF Chaise
33 x 63 x 33"
84 x 160 x 84cm




74 Rectangle Ottoman
37 x 23 x 17"
94 x 58 x 43cm



98 RHF Angled Loveseat
97 LHF Angled Loveseat
65 x 48 x 33"
165 x 122 x 84cm



09 Corner Curve
46 x 46 x 33"
117 x 117 x 84cm



19 RHF Bumper
20 LHF Bumper
54 x 42 x 33"
137 x 107 x 84cm




83 Wedge Seat 22 deg.
23 x 37 x 33"
58 x 94 x 84cm



23 Angled Ottoman
32 x 32 x 17"
81 x 81 x 43cm



85 Wedge Seat 45 deg.
42 x 37 x 33"
107 x 94 x 84cm



40 RHF Sofa Split
39 LHF Sofa Split
91 x 37 x 33"
231 x 94 x 84cm




89 RHF Chair
88 LHF Chair
33 x 37 x 33"
84 x 94 x 84cm

13 RHF Sofa
12 LHF Sofa
77 x 37 x 33"
196 x 94 x 84cm



56 RHF Armless Chair
55 LHF Armless Chair
23 x 37 x 33"
58 x 94 x 84cm



91 Apartment Sofa
81 x 37 x 33"
206 x 94 x 84cm
IA: 60" / 152cm



64 Angled Storage Ottoman
44 x 29 x 17"
112 x 74 x 43cm



95 Chair w/Two Arms
43 x 37 x 33"
109 x 94 x 84cm
IA: 22" / 56cm



77494 JUNO

PALLISER®
My Home, My Style, My Way™

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty


Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty



CONFIGURATION CH

115 x 91"


292 x 231cm



CONFIGURATION C1

88 x 63"


224 x 160cm



CONFIGURATION C2

92 x 91"


234 x 231cm



CONFIGURATION C3

129 x 48"


328 x 122cm



CONFIGURATION C4

124 x 101"


315 x 257cm



CONFIGURATION C5

151 x 51"


384 x 130cm



CONFIGURATION C6

113 x 92"

287 x 234cm



CONFIGURATION C7

101 x 101"

257 x 257cm