
POLYWOOD

Assembly Instructions



NO ASSEMBLY REQUIRED

CDD101 Chippendale Counter Side Chair



20-Year Warranty

To view our full warranty, please visit polywoodoutdoor.com/warranty

Easily register your product using one of the methods below:

Text POLYWOOD to 71403


Receive a link to register online

— or —

Register on our website register.polywoodoutdoor.com

— or —

Send a Picture Take a photo of the icon below and text it to 71403 (US only)





Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 457-3284** or email **support@polywoodoutdoor.com**



• • • • • • • • • • • •

.....

Share your space

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook! #polywood



Watch & Learn

For assembly videos and more, visit **youtube.com/polywood**



Cleaning Tips

Even POLYWOOD gets dirty — here are some ways to help keep it clean:

For a quick clean:

Simply wipe down with soap and water.

For a deeper clean:

You'll need:

- » $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.